



### Quick Start Guide for Watch

Please read this instruction carefully before starting to use the device in order to install and use quickly. Pictures are only for information, take practicality as standard.

### 1. Prepare

Confirm the device type, check the accessories.

Choose GSM network's SIM card, Reference business operator' suggestion. Please turn off the device before install the card.

The watch SIM card need to have GPRS and caller ID function (It must be compatible with 2a of data traffic).

Install client APP on the phone, which can

Bar-code or two-dimension code for user to

### 2. Products function

- platform, double control model
- The phone book
- Talkback
- Health
- Trace
- Watch alarm
- Safety area

inquiry your agency.

- GPS+base station+wifi .Three mode to Mobile phone or Computer GPRS service
- GPRS real-time location, trace, monitor
- Intercom

- SOS emergency alert

Watch remove alert

Low power alarm

Remote turn off

Bumper Dating

### Watch introduce





- asm signal, ringing mode, networking flag, location icon, symbol voice(not shown), light per ception flag, flag battery, below the time, date,
- that send voice phone.

3. Part description and screen



- 3.1 Home page: The first line of small icons were
- 3.2 The phone book: Click to go to see the 15 numbers app settings, click to dial Pick. 3.3 Micro-chat: Point into the micro-chat app
- **3.4 Press intercom:** Press recording, release sent.



- and then with other friends watch bumper post. 3.6 Pedometer: Pedometer off by default, need to open the app inside, after pedometer pedometer will automatically turn on the watch, the data interface can be seen after clicking the number of
- 3.7 Unopened pedometer interface: app pedometer pedometer data will be displayed after 3.8 Download the app: The interface of the two
- -dimensional code is a two-dimensional code to download the app, click on the icon to zoom

into the two-dimensional code, id as shown below watch id number, automatic identification.

# 4. Clients(safe-keeper)operate instructio 4.1 APP register

Before logging in need to manually register the account, registration code scanner 15 or manually enter the registration code registration registration code is unique and can not re-registered, if registered agent is required to restore the corresponding ID number; account must be unique, and others can not repeat, repeat if the user needs to replace the account re-registration; additional information customers can enter their own password can be modified. retrieve password required registration code, login account and fill in the registration phone number, the registration interface as shown

below:

# Account: 416 charac Account: 7893267578 Nickname: 2:16:d report English - Area Europe and

# 4.2.1 APP function menu

After finish register, input the correcter account number and password, click loain, enter the main menu. The main menu show as below: micro-chat screen, press the intercom icon



# Partial function instruction: (1) Inter-phone: Watch talk to mobile phone

App sent voice: After turn on record function. App start to record and sent to watch. The longest voice can be 15s. Micro-end watches into the chat interface short press to play the voice box. Watch for sending recording app: Enter the

recording(The longest record time is 15s), release the recording sent to app; Watch recordings Send to a friend: Press the record button a friend, watches after sending recordings to a friend watches release, the maximum recording 15 seconds. (2) Map: Real-time check the watch's location

The map menu display the watch and APP mobile phone position. Watch start to count for 3 minutes by Click "location". The interval time for upload is 20s. After 3 minutes it will back to the default work style. We can know the pattern of the watch location in real-time on the map menu. When location icon is red it is GPS location, Yellow is LBS location, Green is WIFI location, That green wifi positioning network targeting.

Soo'The family number € Voice working ... Normal mode: 10m/t School time 00:00-23:59

(3) Setting: Parameters setting for watch

(I) weekend time 00:00-23:59 (ii) No disturbing 00:00-00:00 SMS alerts setting Contacts

- a. Set SOS phone number: 3 phone numbers can be set, It will alert after 3S if press SOS key when in emergency situation. Call the 3 phone number periodic. If nobody answer it will be over after two turns. **b. Monitor:** Usually parents' phone number are
- set as monitor number. When confirmed the watch dial the monitor number initiatively, But the

watch can not hear any sound from phone. In that way the phone can monitor watch. c. No disturbing time: The three time shield all

calls(Saturday, excluding weekends).

- d. Message prompt setting: Low voltage, SOS, three kinds of alert message switch when turn off the watch, That number is set wristwatch alarm messages sent to that number, alarm messages according to the normal SMS charges, after the number is set to open by default will monitor
- e. Phone book: 15 phone book numbers can be set in the watch. These 15 numbers can dial to watch in two-wau.
- f. Recover default work model: Default work model-open APP for 24 hours, the upload interval time is 60s.

g. Turn off: It can not press "OFF" key to turn off the watch once it start work normal. Only Through

- friends add friends after the id, and can delete the add friends, watch re-cross a friend, a friend can
- also you can select the model of the watch to meet your needs.

APP to remote turn-off. h. Bumper Dating: Watches will show your

- only be submitted for each watch. (4) Safety area: The smallest radius of the fence
- (6) Award for warm heart: Choose the number of the red hearts, click to send to watch, it will

- is 200m. Alert will happen when for inside of the fence to outside. NOTE: fence alarm only when the watch gps positioning will trigger an alarm message, the base station location is not traveling fence alarm information.

(5) Watch alarm: 3 watch alarm is available and

Personal data Device list (1) Change the password

display the warm heart and the numbers

(7) Seek the watch: Send command while the watch is not at hand, the watch will ring for 1 minutes so that you can find out it. Press any key can stop it.

Clients can know other function will be introduced in "MINE" and "HELP"menu. 4.2.2 "Mine" men

Watch work model

Note: The list of devices which can check customer registration id number, this id and watches posted id inconsistent watches can not connect app.

"HELP" document describe details of all function. Client can go through that.

# 4.3 Watch alert instruction

Client will get alert push when it happens from watch. Phone client click the alert and enter APP main menu to check the details in information

Three base work models: Normal model, Power saving model, Real-time location model. Different models have different interval upload time. Client can set work model based one needs.

Normal model: 600s upload time interval; Power saving model: 3600s upload time interval; Real-time model: 60s upload time interval.

# Watch relative instructions

# 6.1 Watch SOS emergency alert Long press SOS key for 3s. It will display SOS on

screen. Watch will be on alert state. Circular dial 3 SOS numbers for two turns. it will stop when call answered. If not, it will continue until the two turns over. Watch can send message to monitor number(default "off" state) .Also, send alert notification to APP.

# 6.2 Remove wrist alert

There is sensor switch on watchband. It will alert unless you wear the watch for at least 3 minutes. The watch send alert message to monitor number (default "off" state). At the same time sent alert notification to APP. The watch then have remove sumbol.

# 6.3 Low power alert

lower than 20% the alert will happen. The watch send alert message to monitor number(default "off" state). At the same time sent alert notification to APP.

# 6.4 Micro-chat Watch enter the micro chat interface, and

optional micro-chat app. Press and friends watch the recording button to start recording, release the button after sending recordings to watch Friends. Watch received a voice, a voice will mark the screen, press the record button to play all voice finished playing flag disappeared while being removed.

# 6.5 Voice Care Watch care need to set the number, the default

display settings inside guardianship SMS alert number. After the app delivers turn on voice care The watch battery appear in percentage. When instructions, dial the number to care for single talk. 6.6 Shutdown

Watches can be no card keys off, APP remote shutdown, power off.

# 6.7 family number Only one family watch dial keys, press "Mom"

6.8 The phone book Watch app can set up 10 phone book numbers press watch "Mom" to enter the phone book, and then a short press to select the number, and finally press the dial.

corresponding to the number dialed sos1.

# 6.9 Answer and end calls

The number of calls related to watch, touch screen virtual buttons can answer the phone, hang up the power button.

# 7. Trouble shoot 1) The SIM inside watch is GSM networks or not,

such as telecommunications does not support. 2) The SIM card is opened the data traffic, data

traffic must be compatible with 2g of watches currently only 2g of data traffic. 3) Server parameters namely IP and port, ID is

correct, we must ensure consistent and watches factory barcode id id watches posted writes, customers can edit their own mobile phone text messages pw, 123456, ts # sent to watch (wristwatch card must be installed

# power, SMS must be in English input method), if agents do not understand can ask.

4) Not registered in two situations: a prompt device number does not exist or the device number has been registered, must find agents processing; b Tip account that is already registered the account has been registered, the customer can simply change an account.



8. Entrance to scan bar-code

Download Android and IOS for mobile phone client by scan bar-code